



Pretty. Tough. Paint.

Repairing: Scrub Tough

Although the use of Scrub Tough will greatly reduce the need for repainting and will offer an extremely durable and stain resistant finish, it may occasionally get damaged and need repair. Because there is a higher sheen than flat paint, special care must be given when repairing Scrub Tough. Following are some tips that will help the repair process.

- It is very important that the contractor use material from the same batch as the original installation. While Scuffmaster keeps retains of EVERY gallon that we ship to ensure proper color matches, it is possible that there may be a slight variation from batch to batch.
- If the wall to be repaired was damaged, make sure it is repaired to the same level of smoothness as the original installation. This will help the Scrub Tough touch-up blend in with the rest of the wall.
- Thin the material with water. This will help prevent a build up of Scrub Tough that may cause flashing.
- Feather the material, especially around the edges of the repair this will help blend the repair with the original installation. Avoid dabbing.
- If rolling the repair, use a second, clean roller to dry roll the touch up. This will help prevent the possible build up of material.
- Avoid touch-ups on areas that could be cleaned with soap and water. If an area is not damaged, only dirty, always try to wash that area first.
- If the original installation was spray applied, use the same type of equipment, if not the same machine when performing the repair.